ProtoTRAK OFFLINE PROGRAMMING ASSIGNMENT

MEEG 301 30 August 2018


This assignment should not take longer than one hour to complete.

(Note: These instructions apply to ProtoTRAK OFFLINE PT4SXOL, Version 5.11)

THE ASSIGNMENT

For this assignment you will be asked to:

- Download the ProtoTRAK SMX offline software
- Program a sample part
- Take a screenshot of your completed part
- Print out and bring a copy of your screenshot to your machining appointment.



WHY?

Completing this assignment will:

- Prepare you for your machining appointment
- Help you learn how to program the CNC mills
- Make sure you can get your part made in the 2 hour appointment
- Count toward your grade for the machining project

WHERE SHOULD I WORK ON THE OFFLINE PROGRAMMING?

- 1. On your personal PC or laptop. Must be a PC, there isn't a Mac version. Follow the installation steps provided.
- 103 Spencer Lab is already set up as a CAD/CAM Computer lab.
 There will be Office Hours in this lab to help throughout the semester.
- 3. Currently, you cannot install the software onto eCalc machines in Spencer.


WHERE DO I GET THE OFFLINE SOFTWARE?

Go to Southwestern Industries' ProtoTRAK Offline Software page

• http://www.southwesternindustries.com/software#prototrak-


offline-software

 Also can be found by Googling Southwestern Industries, Under Resources & Support click Software



WHICH IS THE RIGHT SOFTWARE TO DOWNLOAD?

- ProtoTRAK offers many software downloads, make sure you get the right one.
- Make sure you are downloading "ProtoTRAK Offline Software"
- Make sure you are downloading for the "SMX & SLX Controls"
- Click "Full Instructions"



HOW DO I DOWNLOAD IT?

- After selecting Full Instructions, select "DOWNLOAD OFFLINE SOFTWARE HERE"
- Follow the onscreen instructions to install

ProtoTRAK OFFLINE PT4SXOL

CURRENT VERSIONS IN THIS RELEASE:

Software 5.11 Parasolid 1.06

Verify 1.08

DXF 3.3

Download Instructions (For Windows XP and later)

Click on the Download button below, and when prompted, choose to save the file to a temporary location, such as your Windows desktop.

DOWNLOAD OFFLINE SOFTWARE HERE SXOL_511h.exe 22.6 MB




HOW DO I RUN ProtoTRAK SMX OFFLINE AFTER I INSTALL IT?


• Step 7 of the installation guide says to look in the C:\PT4SX folder and click on the PT4SX.EXE file. This can be found by going to your Computer's file navigator opening your C: drive then opening the PT4SX folder and double clicking on PT4SX.EXE.

> This PC > Local Disk (C:) > PT4SX ↑ ♣ > This PC > Local Disk (C:) Date modified Туре ▼ This PC Ouick access Name Date modified Type 8/29/2017 2:29 PM Desktop 8/29/2017 2:29 PM File folder Options ccess EaselLocal 5/13/2016 12:45 A... File folder 8/29/2017 2:29 PM File folder эр Documents 8/29/2017 2:29 PM File folder FX Offline 7/19/2017 5:32 PM Pictures 8/30/2017 12:53 PM Text Documen Folders (6) loads 2/18/2016 11:59 A... Files 8/29/2017 2:34 PM Text Documen nents GCodeEditor 1/3/2014 12:21 PM GLANCEY-FIBER-Application PerfLogs 7/16/2016 11:47 A... File folder Desktop **Documents** Desktop Msvcp50.dll 4/15/2008 9:30 AN MEEG 304 Application extens Program Files 8/21/2017 3:49 AM Downloads PT4_InConvert_Config 4/15/2008 9:30 AN Offline Codina Program Files (x86) PT4_InConvert_English.mls 4/15/2008 9:30 AM MLS File 8/21/2017 3:50 AM File folder Documents Downloads Music PT4_PT3Convert_Config 4/15/2008 9:30 AN Configuration setting 7/19/2017 4:10 PM Pictures File folder CEY-FIBER-PT4_PT3Convert_English.mls MLS File 4/15/2008 9:30 AM OneDrive PT4SX 8/29/2017 2:30 PM File folder Configuration setting 3/16/2012 2:02 PM 304 This PC PT4Convert 7/28/2011 4:31 PM Videos Application **Pictures** 5/10/2016 10:58 P... File folder GLANCEY-FIBER- Coding Desktop PT4Input 7/28/2011 4:31 PM Application WORKS Data 5/18/2017 8:22 AM File folder MEEG 304 Documents PT4Output 7/28/2011 4:32 PM Application Devices and drives (1) WORKS Data (2) Downloads 7/28/2011 4:32 PM Offline Coding 8/21/2017 3:57 AM Application Local Disk (C:) PT4SX 10/31/2014 7:49 AM Music Application PARTS 10/28/2016 8:19 P... Pictures Windows 8/21/2017 4:49 AM File folder MIS File 4/15/2008 9:30 AM OneDrive This PC

HOW DO I SET UP MY ProtoTRAK SMX SOFTWARE CORRECTLY?

- If everything was downloaded you should see this.
- If you do not see this, you may have downloaded the wrong software.
- MAKE SURE YOUR YOU SEE SMX ON YOUR SCREEN HERE.
- If you see **SLX**, you will need to click GO TO MILL in the bottom right corner.





WHERE ARE ALL THE BUTTONS?

The full controller in the shop has a whole panel of hard keys on the right on the display that you will not see on your screen.

Display on the Mill in 104 Spencer Lab



Source: xyzmachinetools.com

Offline Software Display



HOW DO I USE THESE BUTTONS?

• Below is a cheat sheet, for Keyboard equivalents for each hard key. This will also be posted to Canvas. You should print this out for your use.

ProtoTRAK SM Key	Keyboard Equivalent	
GO	Alt + G	
STOP	Alt + S	
ACCESSORY	Alt + C	
F/C	Alt + Z	
INC SET	Alt + I	
ABS SET	Alt + A or Enter	
Χ	X	
Υ	Υ	
Z	Z	
MODE	Alt + M or ESC key	

ProtoTRAK SM Key	Keyboard Equivalent	
Numbers 0 - 9	Numbers 0 - 9	
+/-	+ and -, default is	
	positive	
INC/ABS	Alt + [
IN/MM	Alt +]	
LOOK	Alt + L	
RESTORE	Use back/clear key	
SYS	Alt + W	
A	Alt + up arrow	
▼	Alt + down arrow	
HELP	Alt + H	
BACK	Alt + B	
RESTORE IN AGE	Alt + Backspace	


WHAT WILL YOU BE PROGRAMMING?


• Below is a simple model that you will program now, just to get a feel for the basic operation of how to program the 2-axis CNC mills in the shop.

Mr. Nelson and Mr. Ricketts will go into more detail at your machining

appointment.

 You should print out a copy of the final engineering drawing of your plate to work from when you come to your shop appointment.






Program this plate, not your own plate!


	ALE BIVIER GIOTAG IN INCOME				
	TOLERANCES (UNLESS OTHERWISE NOTED)	PROJECT OR CLASS: MEEG	301, FALL 2017		
	DECIMAL .XXX ± .005 .XX ± .010 .X ± .050	DRAWING TITLE: EXAMPLE PART FOR OFFLINE PROGRAMMING ASSIGNMENT			
		DRAWN BY: L. E. SZEWCZAK	DATE: 8/30/2017		
		CHECKED BY:	DATE:		
	FRACTIONAL ± 1/32	APPROVED BY: J. GLANCEY	DATE: 8/30/2017		
		MATERIAL: ALUMINUM	QUANTITY: 1		
	ANGULAR ± 0.5 DEG	SCALE: 1:2	DWG NO: 1 OF 1		
		BILLING ACCOUNT:			


HOW DO I START PROGRAMMING?

- To begin programming, press MODE <ALT+M>
- Click PROG for programming



Type in a Program Name, Hit ENTER Click GO TO BEGIN to program a feature






HOW DO I PROGRAM MY FIRST FEATURE?

- We're going to start by programming the outside shape of our part
- This shape is going to be a rectangular profile.
- Start by clicking PROFILE


PT4SX Offline P/N 123 2 AXIS INCH **PROG EVENT 1** EVENT 0 123 PROGRAM NAME 1 000 SCALE NO **AUXILIARY FUNCTION** NO EVENT COMMENTS MULTIPLE FIXTURES **DIMENSION DEFINITION PART GEO** Select an event F1 F2 F8 **POSN BOLT** EN-ARC POCKET MILL PROFILE MORE DRILL HOLE GRAVE

Then click RECT PROFILE



WHAT TO I NEED TO ENTER IN?


- Read the drawing provided and fill out the feature below.
- We need to program the coordinates of two opposite corners of the rectangle and include the corner radius (CONRAD).



- Type a number and press ENTER to move down.
- If you make a mistake you can move up and down by using the DATA FWD and DATA BACK buttons.
- When you have more features programmed you can go through them by pressing PAGE FWD and PAGE BACK buttons.

DID I DO THAT RIGHT?


 You can and should check your work after every event by pressing LOOK <ALT+L>.




- Your screen should look like this.
- You can return to your programming screen by again pressing LOOK <ALT+L>
- If at any point you get lost press MODE <ALT+M> until you return to the main screen. Then press PROG then GO TO BEGIN, to navigate to your program.

HOW DO I PROGAM THE SECOND FEATURE?


- Second, we will program the rectangle in the top right corner.
- This will be a Rectangular Pocket. Click POCKET then RECT POCKET






THE NEXT FEATURE?


- Next, we will program the circle in the bottom left corner.
- This will be a circular pocket. Click POCKET then CIRCLE POCKET.






HOW DO I PROGRAM A DRILL HOLE?


- The small hole in the top left corner will be a drill hole.
- Click POSN DRILL to select a position/drill move.



HOW DO I ENGRAVE MY INITIALS?

- Click EN-GRAVE to select the engrave feature.
- Make sure you enter <u>YOUR INITIALS</u> as the text.





HOW DO I GET CREDIT FOR MY WORK?

 Take a screen shot of your final LOOK screen that has <u>YOUR INITIALS</u> on it.

Print it out and bring it along with you to your Machining

Appointment in the shop.

 Your screenshot should look like this, it has all 5 features programmed and your initials engraved on it.

